

  
**SPECTRA**  
 User's Quick Reference Guide

**KEYPAD OVERVIEW**

**AC LIGHT**

ON = Power on  
 OFF = Power off

**STATUS LIGHT**

**Green**


ON = All zones closed  
 OFF = Zone(s) open or in tamper  
 FLASH = Exit delay

**Red**

ON = Partition(s) armed  
 OFF = Partition(s) disarmed  
 Slow flash= Stay or instant armed  
 Fast flash= System in alarm

**ICON DISPLAY**

-  1 2 Indicates which partition(s) are Force Armed.
-  1 2 Indicates which partition(s) are Instant Armed.
-  1 2 Indicates which partition(s) are Stay Armed.



1640 Icon LCD Keypad

**ICON DISPLAY (continued)**

Indicates numbers corresponding to open zones, option numbers or troubles.

-  1 2 Indicates which partitions are Regular Armed.
-  Indicates which zone is in Chime Mode.
-  Indicates tampered zones.
-  Indicates a Fire Alarm.
-  Indicates system troubles.
-  Indicates bypassed zones.
-  Indicates alarms stored in memory.

**ARMING AND DISARMING**

**TO ARM  
 WHEN LEAVING...**



**To Regular Arm:** Arm all the zones in the selected partition.

Enter your [ACCESS CODE]\* (or press and hold the  key† for 3 seconds).

**To Force Arm:** Arm partition without waiting for all zones to close.

Press the  key, and then enter your [ACCESS CODE]\* (or press and hold the  key† for 3 seconds).

**TO ARM  
 WHEN STAYING...**



**To Stay Arm:** Arm partition's perimeter, which allows you to remain in the protected partition.

Press the  key, and then enter your [ACCESS CODE]\* (or press and hold the  key† for 3 seconds).

**To Instant Arm:** Stay arm partition, but if any armed zones are breached, it will instantly cause an alarm.

Stay arm and hold the  key† for 3 seconds during the Exit Delay.

**To Disarm:**  
 Enter your [ACCESS CODE]\*.

\* If needed, press button(s) corresponding to desired partition(s). For two partitions, press the other key after the confirmation beep.  
 † Must be enabled by your Installer.

## PANIC ALARMS

To send a silent or audible alarm to your Security Company, press and hold one of the button combinations listed for 3 seconds.

Panic Alarm Type	Button Combinations
Police	Press [1] & [3]
Medical	Press [4] & [6]
Fire	Press [7] & [9]

## TROUBLE DISPLAY

When a trouble condition occurs, the  icon will illuminate.

1. Press the  key. The  icon will flash and number(s) corresponding to the trouble(s) will illuminate.
2. Read the corresponding explanation of the trouble from the trouble list in the 1640 LCD Icon Keypad User Guide. If no repair instructions are given, call your security company for repairs.
3. Press the **X** or the  key to exit.

## BYPASS PROGRAMMING

Bypassed zones remained unarmed when the partition is armed.

1. Press the  key.
2. Enter your [ACCESS CODE]. The  icon flashes.
3. If required, select the partition whose zones you wish to bypass by pressing the [1] or [2] key.
4. Enter the desired two-digit number (i.e. zone 3 = 03) or use the  or  buttons to scroll to the desired zone and press the  key. Repeat to unbypass the zone. If the zone number illuminates, the zone is bypassed.
5. Repeat step 4 until all desired zones are bypassed.
6. Press the  key to exit. The  icon will illuminate.

## ALARM MEMORY DISPLAY

To view the alarms that occurred during the last armed period:

1. Press the  key.
2. The  icon will flash and the corresponding zone numbers that were in alarm the last time the system was armed will illuminate.
3. Press the **X** or  key to exit.

## KEYPAD SETTINGS

You can modify the keypad's settings to suit your needs:

1. Press and hold the [6] key for 3 seconds.
2. Press one of the following keys:
  - [1] Backlight: keypad's light (7 is brightest)
  - [2] Contrast: character intensity (7 is lightest)
  - [3] Scroll: time between messages (7 is the slowest)
3. Press  or  to modify the settings.
4. Press the  key to save.
5. Return to step 2 or press **X** to exit.

## CHIME PROGRAMMING

1. Press and hold the [9] key for 3 seconds.
2. Enter the two-digit zone number of the desired zone or use the  or  buttons to scroll to the desired zone and press the  key. Repeat to unchime the zone. If the zone number illuminates, the zone is chimed. If the zone number is extinguished, the zone is unchimed. To remove chiming from all zones, press the  key.
3. Press the **X** key to exit.

©Paradox Security Systems Ltd., 2003-2004. Spectra is a trademark or registered trademark of Paradox Security Systems Ltd. and its affiliates in Canada, the United States and/or other countries. All rights reserved.